

INSTRUCTIONS FOR USE

MACHINING AND USE

POLGLOS sheets and fronts should be stored in dry rooms in temperature from +10 to +30 degrees Celsius. After removing the protective film the surface of acrylic is soft and can scratch, so it has a seasonal period of about 7 days.

During the seasonal period front surface of board can't be interfered in any way. After removal of the protective film there are traces of dissolving agent on the glossy layer of the board which should evaporate. The seasoning time as well as the evaporation of the dissolving agent can be accelerated up to about 30 minutes using: Vuplex and Ultra Gloss Superpolish - they also serve the daily care of the fronts with acrylic surfaces.

CLEANING

We use only soft cloths (cotton, microfiber) to clean the front surfaces. In addition to the above mentioned cleaning agents (Vuplex, UltraGloss) we can apply a 1% solution of soapy water. It is prohibited to use solvents, abrasives, acids, waxes and other chemically active substances. When using detergents, first try a non-visible surface area. Acrylic elements are suitable for indoor use, places closed and ventilated with regular temperature and humidity. It is unacceptable to use them outdoors. Acrylic fronts are designed for vertical use. Using them in a horizontal position is possible, but any mechanical damage is not covered by the warranty.

NOTE: It is prohibited to use abrasives such as abrasive milk or powders, strong detergents such as solvents, stain removers. Do not use scouring sponges.

We reserve the right to display defects on the POLGLOS acrylic sheet in the size and quantity specified in European standard DIN EN 14323 800-1000 LUX.

Sklejbud sp.j. Rutka